

RFpwrMeter. Pa0nhc 20171222

This scale is for a 60mm x 45mm 1mA / 210 Ohms moving coil meter : Conrad 103538.

Prevent that steel particles enter the meter internal space (strong magnet inside).

- Print this meter scale with **Adobe Reader and size 100%**.
- Cut it along the 57.1mm wide thin rectangle lines
- .
- Clean the work surface.
- Remove the meter lid, and unscrew the meter scale.
- Glue the new meter scale to the **back** of the meter scale plate.
- Install the meter scale plate and close the lid.

